

Lucent Partner II Time Change

To change the system time:

1. Press feature, 0,0, system program, system program, #103
2. Enter a new time in 24 hour notation. For example, to set the time to 2:15 pm, press 1415. The display reads:

System Time

Data 1415

This time appears on system display phones as 2:15p

3. Select another procedure or exit programming mode