

## Prostar Time Change

with handset on hook, dial #06 (pound 06)

dial passcode 1234 then 1 # (pound)

dial #55 (pound 55)

display shows :YY MM DD W HH MM"

YY = last 2 digits of year

MM= Month 01-12

DD= day of month 01-31

W= day of week Monday is 1 Sunday is 7

HH= Hour - use 24 hour clock

MM= minutes 00-59

Dial # (pound) to set current date & time  
the phone will return to normal use