

Simplicity Time Change

Setting The Simplicity Date and Time Must be done any time there is a Local Time change such as Daylight Savings Time.

Call the voicemail system backdoor number

Press #555 or #5555 for the admin mailbox
enter passcode (0000 default)

From the system admin menu press 5
Dial the Date as a six digit number MMDDYY
The date is played back for confirmation

Dial the Time as four digits in 12 hour clock HHMM
Press 1 for AM or 2 for PM
The time is played back for confirmation
Press *